Make sure fasteners are torqued to specified values A WARNING Support parts associated with fasteners that are to be removed for service or product damage and or personal injury may FASTENER: ARM YOKE occur. TOOL SIZE: T-27 TORX BIT WITH RATCHET WRENCH USING SPECIFIED TOOL SIZE, REMOVE FASTENING HARDWARE AND REPLACE. SOME FASTENERS WILL REQUIRE FURTHER TOROUF SPEC: 100-125 IN-LBS. INSTRUCTION FOR REMOVAL PROCEDURE, FOUND IN SERVICE PART INFORMATION MATERIAL. TORQUE FASTENERS TO SPECIFIED AMOUNTS. SEE FIGURE 1. FASTENER: REAR SEAT LINK TOOL SIZE: 10MM SOCKET WITH RATCHET WRENCH FASTENER: BACK SCREW . TOOL SIZE: 5MM HEX BIT WITH RATCHET FASTENER: REAR SEAT LINK WRENCH TOOL SIZE: 4MM HEX KEY TOROUF SPEC: 70-100 IN-LBS. TIGHTEN NUT UNTIL FLUSH WITH END OF SCREW FASTENER: SUPPORT SCREW --FASTENER: RETAINING RING TOOL SIZE: 13MM SOCKET WITH TOOL: RETAINING RING RATCHET WRENCH TOOL TORQUE SPEC: 200-250 IN-LBS. FASTENER: TILT SET SCREW TOOL SIZE: 4MM HEX KEY FASTENER: HIP PIVOT SCREW TOOL SIZE: 6MM HEX BIT WITH RATCHET WRENCH FASTENER: SWING ARM (PRE 9-16-98) TOOL SIZE: T-48 TORK BIT TOROUE SPEC: 189-200 IN-LBS WITH PATCHET WRENCH TORQUE SPEC: 120-150 IN-LBS. FASTENER: FRONT SEAT LINK TOOL SIZE: SHIM HEX BIT WITH RATCHET WRENCH

TORQUE SPEC: 120-150 IN-LBS

NOTICE